2 Function + Keypad with Mini Transmitter

SYSTEM PART NUMBER

92002K

2 Function Receiver with Master + Keypad + 2 Function Mini Transmitter

REPLACEMENT TRANSMITTERS

9TX002 2 Function Mini Transmitter – with legacy software





CONTENTS

- 1 x Receiver + Keypad
- 1 x Mini Transmitter
- **1 x** Lanyard
- 1 x Instructions

TRANSMITTER SPECIFICATION

ENCLOSURE

Material Switch Type Functions Identification

RF

Modulation Frequency Channels Channel Selection Technology Temperature Range Range Registration Codes Aerial

POWER

Batteries Quiescent Current Current Standby (SET) Current Transmitting RF Radiated Power

SAFETY & PROTECTION

IP Rating Reverse Polarity Protection

INFORMATION

Transmit Indication Fault Codes Low Battery Legacy Software

COMPLIANCE

See compliance documentation

ABS Silicone Rubber keypad with carbon pill 2 Subsurface printed transmitter label

2-GFSK. Gaussian Frequency Shift Keying 433.050 MHz to 434.790 MHz

Fixed Hand-held Transmitter -10° C to + 40° C (13° F to + 104° F) 45m (150ft) Over 16 million Internal – printed on PCB

2 x AAA – 3 volts. 5µA 2mA 30mA 0dBm

1

67 Yes – MOSFET

LED on when TX operated LED flashes fault code LED flashes when TX operated Software update to work with 9 series

RECEIVER SPECIFICATION

KEYPAD

Back up Control

SWITCH TYPE Output Switching

SUPPLY VOLTS

Nominal Absolute Maximum Minimum **Output Switch Supply**

AMPS

FET Rating System Rating Quiescent Current **Overload Protection**

AERIAL

Internal Antenna External Antenna

OUTPUTS

Master Function

CONFIGURATION

RS232 Programming

PERFORMANCE

requirements parallel master inhibit, timeout, channel timeout delay, master on delay, radio button de-latching and output allocation.

With horizontal interlocks (Interlocks are programmable - see CONFIGURATION above)

Not all models, see Build Specification Table. For programming interlocks, push/push latch, to user's

Simultaneous Outputs
Instant TX response

onse	Yes	No perceivable delay between TX operation and RX action

Yes Con	firm 5 Volts, SET,	Fault and all Outputs.
---------	--------------------	------------------------

Works independently from the Transmitter

MOS Field Effect Transistor (P Channel Power MOSFET)

Security coding available as an option

12/24 Volts DC 40 Volts DC

Internal 12/24 Volts

25 mA on Standby (Not SET)

15 Amps (Auto Shutdown)

Supplied and fitted

See Accessories.

8 Volts DC

15 Amps

15 Amps

Yes

Yes

Yes

Yes

2

Optional

PROTECTION


DIAGNOSTICS LED's

ESR Safety	Yes	See ESR Safety document.
Back EMF	Yes	Diode protected on all outputs
Registration codes	Yes	Over 16 million
STOP Connection	Yes	Internal Emergency Stop Connection. Not all models, see Build Specification Table.

WIRING

Wiring Loom	Yes	3 metres (10ft) supplied and fitted
Cable Gland	Yes	Supplied and fitted
Connections		Screw terminal into plug and socket on PCB, for easy "swap out"

ENCLOSURE



Weight Lid Base Breather Mounting Fixings **IP** Rating

0.3 lbs (335gms) Clear PVC - to view LEDs Black PVC Gortex fitted in base 4 external lugs 5mm (3/16") not supplied IP66

92 Series				K	4	0	2	4
BUILD SPECIFICATION TABLE FOR MODELS IN THIS RANGE			92000	92002K	92004	92100	92102	92104
Ident	Legend	Connection	0,	σ	0,	0,	•	•,
	+ - F1 F2	Positive, Negative, F1 and F2	S	S	S	S	S	S
	F3 F4 M	F3, F4, and Master		М	S		М	S
	ST -	STOP and -		S	S		S	S
	S+ S-	S+ S-		S	S		S	S
	ANT	Internal Antenna	S	S	S	S	S	S
	SMA	Connector (external antenna)		S	S		S	S
LK1	Р	Master - Parallel		С	С		С	С
LK2	С	Master – Continuous		С	С		С	С
LK3	RS232	RS232		S	S		S	S
		3 metres 4 core	S			S		
		3 metres 7 core		S	S		S	S
		9801 Lo-Cover				S	S	S

S = Standard. M = Standard but Master only connected. C = Customer configured (see "Factory Settings").

+ -	Positive 12/24 Volt supply Negative 0 Volts
F1, F2, F3 & F4	Outputs to F1 through F4
Μ	Master Output
STOP -	STOP, when grounded shuts down the Receiver
S+ S-	Master Secondary for Safety solenoid connections etc.
ANT	Blade connector for internal antenna
SMA	Aerial connection for optional external antenna (internal antenna must be removed)
LK1	Jumper fitted to this link for continuous Master
LK2	Jumper fitted to this link for parallel Master
Factory Settings	418MHz configured Parallel, 433.92MHz configured Continuous
LK3	RS232 for interface to access special programmes
	Also for connection to RS232 modules

Photo of PCB

Connector Side



Component Side

